


How BNC Crimps and Combo BNC Cables work

1. Strip open the BNC combo cable and separate the power from the BNC



2. Slip on the crimping part of the BNC2 Connector, making sure the inner metal conduct inserts correctly into the BNC female.



Website: www.CCTVSecurityPros.com

3. Crimp at the following locations with the crimping tool.



Crimp @ These locations

Website: www.CCTVSecurityPros.com

CCTV SecurityPros.com
Seeing is Believing