



1. From the Main Menu Select Storage.




2. Select HDD Manage.




Note. The next step of this guide will erase all of the recorded video stored on your HDD. Only perform the Format if you would like to erase **ALL** recorded video.


3. Choose HDD to format.




4. Select Format.



5. Select "Yes" to verify format.



6. Click Apply → Click Save. Device will reboot after changes made.



Note. This will erase all of the recorded video stored on your HDD. Only perform the format if you would like to erase ALL recorded footage.