


How to Setup Push Notifications via SCS Plus or SCS HD Plus


The following guide will only apply to the paid versions of our SCS Applications.

SCS Plus and SCS HD Plus

Navigate to **Main Menu->Setting->Storage**




Select **Storage** on the left Column. Make sure **All** cameras are **enabled** for the **Sub Stream** or **Extra Stream** as seen below. Click **Save**.




We can now change gears to your Mobile Device. Open up your **SCS Plus** or **SCS HD Plus** App.

Select the **Menu Icon** on the top left hand side of the App and Select **Alarm Manager**. Select **Push Config**.




Select your added **Device**.




Enable the Device at the top.

Select the Type of Alarm you would like to Enable.



Select which camera or cameras you would like to enable the Alarm on. Once you have your cameras selected tap on the **Back Button** at the top left.



Once you hit the **Back Button**. Make sure to **Save** your configuration by selecting the **Disk** icon at the top.

