

RG59 / Power (Siamese) Cabling (For Analog & HD-CVI Cameras):

- ▶ Strip the black (-) and red (+) wires on both ends of the siamese cable (Figure A).
- ▶ Strip the RG59 side on both ends of the siamese cable (Figure A).
- ▶ Terminate both ends of the RG59 side with a BNC connector (Figure B).
- ▶ Connect the power side of the siamese cable to a terminal inside the power box.
- ▶ Be sure to match the negative (-) and positive (+) sides of the power cable and terminal.
- ▶ Plug the BNC video side of the siamese cable into a video input on the back of the DVR.
- ▶ Every camera comes packaged with a male pigtail, to be used on the camera side.
- ▶ Splice the black (-) and red (+) wires of the siamese cable and pigtail together.
- ▶ Connect the male pigtail and BNC video connector to the camera harness.

