


Modifying Password

Passwords need to be altered on occasion for several reasons. If you would like to update the password of an existing user please continue reading below

Right click on the main screen and navigate to the **Menu -> System -> User**. Select the **Edit** button next to the user you would like to modify.



Start by entering your **Old Password**. This must be the correct old password. If you are still using the default password it will be '123456'. Enter your new **Password** and **Confirm** the new password below. You may Enable an **Unlock Pattern** if you would like to login using the pattern. Please note the unlock pattern is completely optional and does not need to be used. Select **OK** when you are complete.

