



How to Setup Smart Motion Detect Notifications with SCS Pro

*Smart Motion Detection will only work with SMD enabled equipment. SMD must be enabled in the recorder prior to use.

Start by opening the **SCS Pro** App. Fullscreen the camera you would like to enable motion alerts on.
Select the Gear
icon at the top right.




Ensure the correct camera is selected and click on Notification.




Enable the alarm notifications by sliding the switch at the top of the screen.


Select which type of alert you would like to enable below. This example will show motion detection alerts.



Click the box next to SMD to enable it. Click the arrow to return to the previous screen.



Click Save once you have selected all of the alerts you would like to receive.



You will now be receiving alerts on your mobile device.
You may need to alter your SCS Pro App settings inside
of your phone or tablet to allow notifications.

